




---

## INSTRUCTIONS

---



## **PARTS SUPPLIED:**

- Monkey Bar x 1
- Monkey Bar Accessory Pack x 1
  - a. 8g x 35mm Stainless Steel Pan Self-Tappers x 3
  - b. M5 Stainless Steel Washers x 3
  - c. Ø6 x 35mm Wall Plugs x 3
  - d. Plastic Endcaps x 2
  - e. Installation Instructions

## **INSTALLATION (MONKEY BAR):**

Step 1. Remove contents from the packaging.

Step 2. Determine the best location to store your Bin Monkey. The top fixings must be set at least 750mm above FFL (Finished Floor Level) so the Monkey Bar handle clears the floor when installed. (See Fig. 1)

NOTE: If there are small children present fit the Monkey Bar at a height that will prevent any accidental head knocks.

Step 3. Mark the fixing holes at the correct centres. You can use the Monkey Bar itself as a template.

Step 4.

- A. If installing into **masonry** drill a Ø6.0mm hole at a minimum 40mm deep using a masonry bit and hammer drill. Fit the 35mm wall plugs and secure the Monkey Bar to the wall using the 8g x 35mm pan self-tappers provided.
- B. If installing to **timber** drill Ø3.0mm pilot holes and screw the Monkey Bar directly to the wall using the 8g x 35mm pan self-tappers provided.

## **LIMITATIONS:**

Bin Monkey makes no express warranties or representations other than is set out in this warranty. The repair or replacement of the product or part is the absolute limit of Bin Monkeys liability under the express warranty. Our goods come with guarantees that cannot be excluded under Australian consumer law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

## **LOCATION:**

### **Head office:**

PO Box 698, Mount Martha, Vic 3934

T: +61 436 302 654

E: [dean@binmonkey.com.au](mailto:dean@binmonkey.com.au)

W: [binmonkey.com.au](http://binmonkey.com.au)

## **PROOF OF PURCHASE:**

Proof of purchase must be retained. Please attach your receipt and keep in a safe place for future reference.

## **WARRANTY:**

Subject to the exclusions below, Bin Monkey warrants:

- ***For 12 months from date of purchase:*** the repair or replacement, in its discretion, of any product that fails to operate correctly due to faulty workmanship or defective materials.

The benefits of this warranty are in addition to the non-excludable rights and remedies imposed by Australian State and Federal legislation.

## **WARRANTY CLAIMS:**

To make a warranty claim please contact your place of purchase or our head office with alleged defect. Ensure you have retained your receipt as proof of purchase. Where necessary Bin Monkey will arrange an inspection of your product.

You must bear all costs associated with making a warranty claim, including returning the product or components by freight. Where deemed your warranty claim is valid, we will bear all costs associated with repairing or replacing the defective product.

## **WARRANTY EXCLUSIONS:**

The warranty does not cover:

- Defects caused through misuse or abuse.
- Incorrect adjustments or unauthorised repairs.
- Defects caused by incorrect installation.
- Product damage or deterioration due to abnormal environmental conditions including extreme coastal, storm damage, fire, wind, humidity, pressure, stress or similar.
- Powder coat deterioration caused by exposure to sea air where the product is installed in a coastal environment.
- Defects caused by normal wear and tear.




Fig.1 – Hole Positions

**NOT TO SCALE**